



Distances are approximate to the center of the holes: Hole Size

Overflow	down 4"	1 ½"
Spigot	up 12"	1 ½"
Drain	up 4"	1 ½"

Thread in elbow until tight, slip on approx. 5' of drain hose
 Thread spigot into bulkhead fitting w/Teflon tape on threads, install bulkhead fitting
 Thread brass fitting into bulkhead fitting, thread on hose adapter until tight.
 Install bulkhead fitting.